

SPEAKER AND VOLUME CONTROLS

Jumper JP4 when installed mixes all sounds to both amplifiers. When JP4 is not installed the bell and whistle sounds come out of speaker #1 only and the chuff from speaker #2 only. Volume and balance are accomplished by the volume knobs; cont.#1 adjusts the bell and whistle volume and cont. #2 adjusts the chuff and idle volumes. Normally, when adding speaker #2, the jumper would be removed unless you want all sounds out of both speakers.

MANUAL/AUTO MODES

Jumper JP6 controls the mode of the sound playback.

The horn/bell pin when in manual mode gives the operator full control of the sounds when used with a remote or radio control. In the auto mode preprogrammed sequences are played.

The starter/cab talk is primarily used on diesels.

**THIS CIRCUIT BOARD DIAGRAM APPLIES TO ALL SOUND SYSTEMS PRODUCED
AFTER 11-01-1997**

